



Throttle Cable (3VZE/22RE) Installation Instructions

Installation of the throttle cable bracket is very simple.

- **Begin by removing the cruise control assembly from the OM617**
- **Remove the black plastic over the OM617 throttle linkage**
- **Remove the 2 bolts from the driver side of the valve cover (13mm drive)**
- **Install the new throttle cable bracket on top of the existing bracket, and use existing bolts to fasten**
- **Guide throttle cable thru new bracket and hand tighten nuts to hold cable in place**
- **Install Lokar throttle cable attachment to pivot plate shown in picture**
- **Cut throttle cable and insert it into Lokar attachment**
 - **A cut off wheel provides a clean cut**
 - **Only cut of as much as required, to provide ample adjustment**
- **Tighten Lokar attachment**
- **Use 2 throttle cable nuts and Lokar attachment to adjust cable tension**
- **If throttle cable is slow to return, an additional spring can be added to the system**

